

FITTING INSTRUCTIONS FOR DRYING CABINET ETS 1100

Note! This drying cabinet is intended for permanent on-wall installation.

INSTALLATION

1. Screw the cabinet onto the wall through the four holes in the cabinet wall. The cabinet must be hanging in balance.
2. Fit the outlet flange into the most suitable outlet opening.
3. For optimum efficiency and evacuation of moist air, the drying cabinet should be connected to the ventilation ducting. Connection is by use of the flexible hose from the outlet flange to the draught connector which is fitted into the existing ventilation duct.
4. In operation, about 40 m³ of moist air is evacuated from the cupboard per hour. This air is drawn from the room in which the cabinet is placed.
Ensure that there is an adequate air supply to the room.

ELECTRICAL INSTALLATION

The drying cabinet is intended for single-phase 230-240 V AC operation and must be earthed. The mains cable supplied (1.75 m approx.) must be protected by a 10 A fuse.

